FUNROLUX

FOLDING DINING TABLE
INSTALLATION NOTES



L60*W31.5*H28.7inch



Installation Instructions

First unpack, arrange the boards with the same number and put them together, then install it according to the numbers, which makes it quicker and easier to install.



Number	Quantity	Number	Quantity	Number	Quantity	Number	Quantity
①	1	⑥	1	⑪	1	⑯	2
②	2	⑦	1	⑫	2	⑰	2
③	2	⑧	1	⑬	2	⑱	2
④	1	⑨	2	⑭	2		
⑤	1	⑩	1	⑮	2		

A	32PCS
ϕ15*10mm	

B	32PCS
ϕ6*28mm	

C	16PCS
ϕ8*40mm	

D	2PCS
M6*18mm	

E	88PCS
M3.5*14mm	

F	4Pairs
12"	

G	
G1 3PCS	G2 3PCS
	M4*18mm

H	12PCS
M7*38mm	

I	8PCS

J	2PCS

K	2PCS

L	16PCS
M5*16mm	

M	2PCS

N	2PCS

O	8PCS
M3.5*40mm	

1

Disassembly and installation of accessories

You will need to detach the rails before starting the installation. There is a piece of plastic on the rail, push it up and pull the F2 out to split it in two.



F	4PCS
	
12"	

How to install part number A and part number B. (As the picture shows)



2



C	8PCS
	
ø8*40mm	

3



E	4PCS
M3.5*14mm	

F_1	2PCS
12"	

4



C	8PCS
ø8*40mm	

5



E	4PCS
M3.5*14mm	

F_1	2PCS
12"	

6



B	6PCS
ϕ6*28mm	

7

Ax4



A	4 PCS
ϕ15*10mm	

8



A	2 PCS
ϕ15*10mm	

9



B	6PCS
ϕ6*28mm	

10



A	6 PCS
ϕ15*10mm	

11



H	12 PCS
M7*38mm	

12



B	12PCS
ϕ6*28mm	

13





A	12 PCS
ϕ15*10mm	

14

Bottom up



N	1PC

E	24 PCS
M3.5*14mm	

I	4PCS

15



N	1PC

E	24PCS
M3.5*14mm	

I	4PCS

L	16PCS
M5*16mm	

J	2PCS

K	2PCS

16



E	6 PCS
M3.5*14mm	

D	1 PC

17



E	6 PCS
M3.5*14mm	

D	1 PC

18











x2

E	8PCS
M3.5*14mm	

F_2	4PCS
12"	

G	
G1 2PCS	G2 2PCS
	M4*18mm

O	8 PCS
M3.5*40mm	

B	8 PCS
ϕ6*28mm	

A	8 PCS
ϕ15*10mm	

19



E	12PCS
M3.5*14mm	

G	
G1 1PC	G2 1PC
96#	M4*18mm

M	2PCS

20



21



22





OK


You can put the mute sticker here if you want,
there will be no noise when you move the table。